





757-842-6497
WWW.JLOSC.COM

**J&L 3.0 Oil Separator (2011-2024 Dodge Durango 5.7 Hemi, 2011-2021 Jeep Grand Cherokee 5.7 Passenger Side) #3066P
Installation Instructions**

WE HIGHLY RECOMMEND WATCHING OUR INSTALL VIDEO!!!!

To view install video: go to our website, www.Jlosc.com and type 3066P in search box. Click on product, scroll down and click on videos.

Please review complete instructions prior to installing.

Step#	
1	Verify you have all of the following parts included in the kit: (1) J&L Oil Separator w/Hoses, (1) J&L Mounting bracket, (2) Fine thread machine screws, (2) 1/2" Couplers, (2) 1/2" to 5/8" Couplers
2	Gather all of the following tools needed for the installation: 15mm socket and ratchet (longer the better), Phillips screwdriver
3	Remove engine cover by pulling straight up on the front.
4	Remove plastic portion of the PCV line that runs from rear of engine to the front. The plastic hose is installed into two rubber ends. You may need to use pliers to loosen rubber on plastic hose. Remove the rubber 90 degree coupler from the intake manifold and flip it (install short side onto manifold) 
5	Find the 15mm bolt on the top of the alternator, remove it and install J&L Mounting bracket using same bolt and retighten. 

Note: Use the year range below as a guide, but if you have a 2019+ Vehicle, please test fit connections prior to installing into J&L Hoses to ensure what size you need.
Before installing the couplers, slide dress up ends over hose ends.

2011-Mid 2019 owners – Lubricate the end of the J&L hoses with light oil on a Q-Tip. You will use the Supplied J&L ½" straight couplers.

Late 2019+ Owners- Lubricate the end of the J&L hoses with light oil on a Q-Tip. You will use the Supplied J&L ½" to 5/8" reducing couplers.



6

Take the J&L Oil separator and start to feed the hoses under the wiring harness while getting the can into place under the bracket. One in place use two supplied mounting screws to mount can to bracket.

You will want the longer hose to be on top of the shorter hose in the routing



7

Reinstall engine cover, to reseal the rubber grommets you may need to give it a good "pop" with your hand to fully seat it.

8



To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles. Thank you for your business. If you have any questions, please e-mail info@JLosc.com or call 757-842-6497. Our hours are Monday-Friday. 8:00am – 4:30pm Eastern Time.

J&L Oil Separator co. Lifetime Satisfaction Guarantee. We want you to be a J&L customer for life! Your new J&L product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. www.JLosc.com/warranty

We guarantee workmanship and even a pathway to discounted upgrades for substantially improved items.

Return Policy: All returns will be subject to a 10%-25% restocking fee. Please visit www.JLosc.com for complete return policy.

Disclaimer: J&L Oil Separator co. makes no warranties whatsoever, expressed, or implied, oral or written to any purchasers, except the warranty above. J&L Oil Separator co. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by J&L Oil Separator co. agree to hold harmless and indemnify J&L Oil Separator co. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to J&L Oil Separator co. for any claims arising out of use of its products.